MiBOXER®

Mi·Light
Subordinate New Brand

Panel Remote

Model No.: B4B

1. Features


We adopt a high precision capacitive touch screen IC. Touch screen is very stable; 2.4GHz high RF wireless control with long distance controlling, low power consumption and high speed transmitting rate.

This product has T series and B series, and the difference is the method of power supplying. Both series have 4 kinds: T1/B1 4-zone dimmable panel remote; T2/B2 CCT 4-zone panel remote; T3/B3 4-zone RGB/RGBW panel remote; T4/B4 4-zone RGB+CCT panel remote. This product widely work on our smart LED Lighting, LED controller and smart panel controller, etc.


2. Parameters

B Series: Powered by 3V(2*AAA Battery)

Working Voltage: 3V(2*AAA Battery)
Standby Power Consumption: 20uA
Transmitting Power: 6dBm
Transmission Frequency: 2.4GHz
Working Temp.:-10~40°C
Control Distance: 30m
Size: 86*86*16mm



B4B Function Keys
4-Zone Panel Remote (RGB+CCT)



Touch color slider, choose the color you want.

Under white light mode, adjust color temperature;
Under color light mode, change color saturation.

Touch dimming slider to change the brightness from 1~100%.

White — Touch white button to white light mode.

Mode — Switching modes.

Speed- — Slow the speed on present dynamic mode.


Speed+ — Accelerate the speed on present dynamic mode.


ALL ON: Touch to turn on all linked lights.
Long press 5 seconds to turn ON the indicating sound.
Zone(1-4) ON: Touch zone ON, turn on zone-linked lights.


ALL OFF: Touch to turn off all linked lights.
Long press 5 seconds to turn OFF the indicating sound.
Zone(1-4) OFF: Touch zone OFF, turn off zone-linked lights.

4. Link / Unlink (B4B)

Linking Instructions










1. Switch off the light, after 10 seconds switch on again.
2. When the light on, short press any zone of "⏻" 3 times within 3 seconds.
3. The light blink 3 times slowly means the linking is done successfully.

If the light not blink slowly, the linking failed, pls switch off the light again, and follow the above steps again.

Unlinking Instructions








1. Switch off the light, after 10 seconds switch on again.
2. When the light on, short press "⏻" 5 times within 3 seconds.

   Unlinking must be the same zone with the Linking
3. The light blinking 10 times quickly, means the unlinking successfully.


If the light not blink quickly, the unlink failed, pls switch off the light again, and follow the above steps to unlink again.

5. Installation


B series Installation




1. Tear out the back tape.



2. Stick the holder on the position where you want.



3. Install 2*AAA battery.



4. Put the rotating switch on the front of holder.

6. Attention

1. Please check the cable, and make the circuit is correct before power on.
2. When installation, please handle with care to avoid the broken of the T series glass panel.
3. Please do not use lighting fixtures around the mental area and high magnetic field, otherwise, it will badly affect the control distance.

Made in China