
LED Technologies
Creative LED & Effect Technology for the Trade Professional

MiBOXER® | Mi·Light Subordinate New Brand

Wiring Instructions for Push Switches

INSTALLATION GUIDE



1.Open the front olate,insert the screw into the middle board.
2.Fit the middle board into the mounting box, fasten the screw.
3.Cover the front plate. Finish the installation.

SWITCH WIRING DLAGRAMS

GANG-E008/ GANG-E009/ GANG-E010

