
RF Receiver

Important: *Read All Instructions Prior to Installation*

Function introduction



Product Data


Input Voltage	Output Current	Output Power	Remarks	Size(LxWxH)
12-24VDC	3x5A	3x(60-120)W	Constant voltage	145x46.5x16mm

- Radio Frequency : 868mhz
- Waterproof grade: IP20

Safety & Warnings

• DO NOT install with power applied to device.
• DO NOT expose the device to moisture.

Wiring Diagram



Pair/delete the pairing with RF remote

1.Do wiring according to connection diagram.
2.Pair RF Receiver with RF remote: please refer to the instruction of the remote that you would like to pair with.
3.Delete the pairing:
(1)Wire up the RF receiver correctly, power on.
(2)Press and hold down the **" RF Code Key"** button on receiver for over 3 seconds until the connected light flashes, which means well deleted.